



Huck® BobTail®

Tooling/Nose Assembly Selection

NOSE ASSEMBLY	FASTENER TYPE	FASTENER DIAMETER	FASTENER DIAMETER	LENGTH	RELEASE (JAWS)	COMMENTS	BATTERY TOOL	PNEUDRAULIC TOOL	HYDRAULIC TOOL
99-7820	BobTail	12MM	12MM	STD	SR	—	N/A	N/A	BTT35LS
99-7820CX	BobTail	12MM	12MM	STD	SR	Collar Cutter	N/A	N/A	BTT35LS
99-7821	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	—	N/A	N/A	BTT35LS
99-7821CX	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	Collar Cutter	N/A	N/A	BTT35LS
99-7821X	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	Coated Anvil	N/A	N/A	BTT35LS
99-7822	BobTail	20MM	20MM	STD	SR	—	N/A	N/A	BTT35LS
99-7822CX	BobTail	20MM	20MM	STD	SR	Collar Cutter	N/A	N/A	BTT35LS
99-7824	BobTail	14MM	14MM	STD	SR	—	N/A	N/A	BTT35LS
99-7824CX	BobTail	14MM	14MM	STD	SR	Collar Cutter	N/A	N/A	BTT35LS
99-7825	BobTail	-16	1/2"	STD	SR	—	N/A	N/A	BTT35LS
99-7825CX	BobTail	-16	1/2"	STD	SR	Collar Cutter	N/A	N/A	BTT35LS
99-7826	BobTail	-24	3/4"	STD	SR	—	N/A	N/A	BTT35LS
99-7830	BobTail	12MM	12MM	STD	SR	—	N/A	N/A	3585/3585PT
99-7830CX	BobTail	12MM	12MM	STD	SR	Collar Cutter	N/A	N/A	3585/3585PT
99-7831	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	—	N/A	N/A	3585/3585PT
99-7831CX	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	Collar Cutter	N/A	N/A	3585/3585PT
99-7832	BobTail	20MM	20MM	STD	SR	—	N/A	N/A	3585PT
99-7832CX	BobTail	-24, 20MM	3/4" & 20MM	STD	SR	Collar Cutter, 3585PT required for 20MM	N/A	N/A	3585/3585PT
99-7834	BobTail	14MM	14MM	STD	SR	—	N/A	N/A	3585/3585PT
99-7834CX	BobTail	14MM	14MM	STD	SR	Collar Cutter	N/A	N/A	3585/3585PT
99-7835	BobTail	-16	1/2"	STD	SR	—	N/A	N/A	3585/3585PT
99-7835CX	BobTail	-16	1/2"	STD	SR	Collar Cutter	N/A	N/A	3585/3585PT
99-7836	BobTail	-24	3/4"	STD	SR	—	N/A	N/A	3585/3585PT
99-7840	BobTail	12MM	12MM	STD	SR	—	N/A	N/A	2620
99-7840CX	BobTail	12MM	12MM	STD	SR	Collar Cutter	N/A	N/A	2620
99-7845	BobTail	-16	1/2"	STD	SR	—	N/A	N/A	2620
99-7845CX	BobTail	-16	1/2"	STD	SR	Collar Cutter	N/A	N/A	2620
99-7850	BobTail	12MM	12MM	STD	SR	—	N/A	N/A	BTT25-DT
99-7850CX	BobTail	12MM	12MM	STD	SR	Collar Cutter	N/A	N/A	BTT25-DT
99-7851	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	—	N/A	N/A	BTT35-DT
99-7851CX	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	Collar Cutter	N/A	N/A	BTT35-DT
99-7852	BobTail	20MM	20MM	STD	SR	—	N/A	N/A	BTT57-DT
99-7852CX	BobTail	-24, 20MM	3/4" & 20MM	STD	SR	Collar Cutter	N/A	N/A	BTT57-DT
99-7853	BobTail	-28	7/8"	STD	SR	—	N/A	N/A	BTT57-DT
99-7853CX	BobTail	-28	7/8"	STD	SR	Collar Cutter	N/A	N/A	BTT57-DT
99-7854	BobTail	14MM	14MM	STD	SR	—	N/A	N/A	BTT25-DT
99-7854CX	BobTail	14MM	14MM	STD	SR	Collar Cutter	N/A	N/A	BTT25-DT
99-7855	BobTail	-16	1/2"	STD	SR	—	N/A	N/A	BTT25-DT

*Suggested tool/nose assembly option. Other tooling options may exist. Visit the Tooling Resource Center at AFSHuck.net/Tooling or call HFS at 800-278-4825 or email at sales.kingston@howmet.com for more information





Huck® BobTail®

Tooling/Nose Assembly Selection

NOSE ASSEMBLY	FASTENER TYPE	FASTENER DIAMETER	FASTENER DIAMETER	LENGTH	RELEASE (JAWS)	COMMENTS	BATTERY TOOL	PNEUDRAULIC TOOL	HYDRAULIC TOOL
99-7855CX	BobTail	-16	1/2"	STD	SR	Collar Cutter	N/A	N/A	BTT25-DT
99-7856	BobTail	-24	3/4"	STD	SR	—	N/A	N/A	BTT57-DT
99-7857	BobTail	-32	1"	STD	SR	—	N/A	N/A	BTT57-DT
99-7857CC	BobTail	-32	1"	STD	SR	Collar Cutter	N/A	N/A	BTT57-DT
99-7860	BobTail	12MM	12MM	STD	SR	—	N/A	N/A	SFBTT15
99-7860CX	BobTail	12MM	12MM	STD	SR	Collar Cutter	N/A	N/A	SFBTT15
99-7861	BobTail	-16	1/2"	STD	SR	—	N/A	N/A	SFBTT15
99-7862	BobTail	14MM	14MM	STD	SR	—	N/A	N/A	SFBTT15
99-7862CX	BobTail	14MM	14MM	STD	SR	Collar Cutter	N/A	N/A	SFBTT15
99-7863*	BobTail	-28	7/8"	STD	SR	—	N/A	N/A	SF46-250-02*
99-7863CX	BobTail	-28	7/8"	STD	SR	Collar Cutter	N/A	N/A	SF46-250-02
99-7864	BobTail	-24	3/4"	STD	SR	—	N/A	N/A	SF46-250-02
99-7864CX	BobTail	-24, 20MM	3/4" & 20MM	STD	SR	Collar Cutter	N/A	N/A	SF46-250-02
99-7865	BobTail	20MM	20MM	STD	SR	—	N/A	N/A	SF46-250-02
99-7867*	BobTail	-32	1"	STD	SR	—	N/A	N/A	SF46-250-02*
99-7867CX	BobTail	-32	1"	STD	SR	Collar Cutter	N/A	N/A	SF46-250-02
99-7868CX	BobTail	-16	1/2"	STD	SR	Collar Cutter	N/A	N/A	SFBTT15
99-7880*	BobTail	12MM	12MM	STD	SR	—	N/A	N/A	SF20*
99-7880CX	BobTail	12MM	12MM	STD	SR	Collar Cutter	N/A	N/A	SF20
99-7880X	BobTail	12MM	12MM	STD	SR	Coated Anvil	N/A	N/A	SF20
99-7880X-3	BobTail	12MM	12MM	LONG	SR	Coated Anvil, 3" Extension	N/A	N/A	SF20
99-7881*	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	—	N/A	N/A	SF20*
99-7881-2	BobTail	-20, 16MM	5/8" & 16MM	LONG	SR	2" Extension	N/A	N/A	SF20
99-7881-4	BobTail	-20, 16MM	5/8" & 16MM	LONG	SR	4" Extension	N/A	N/A	SF20
99-7881CX	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	Collar Cutter	N/A	N/A	SF20
99-7882*	BobTail	-16	1/2"	STD	SR	—	N/A	N/A	SF20*
99-7882-4	BobTail	-16	1/2"	LONG	SR	4" Extension	N/A	N/A	SF20
99-7882CX	BobTail	-16	1/2"	STD	SR	Collar Cutter	N/A	N/A	SF20
99-7884*	BobTail	14MM	14MM	STD	SR	—	N/A	N/A	SF20*
99-7884CX	BobTail	14MM	14MM	STD	SR	Collar Cutter	N/A	N/A	SF20
99-7893*	BobTail	20MM	20MM	STD	SR	—	N/A	N/A	SF32*
99-7893CX	BobTail	-24, 20MM	3/4" & 20MM	STD	SR	Collar Cutter	N/A	N/A	SF32
99-7894*	BobTail	-24	3/4"	STD	SR	—	N/A	N/A	SF32*
99-7895	BobTail	20MM	20MM	LONG	SR	—	N/A	N/A	SF32L
99-7896	BobTail	-24	3/4"	LONG	SR	—	N/A	N/A	SF32L
99-7903*	BobTail	10MM	10MM	STD	SR	—	N/A	256BT*	2583*
99-7903CC	BobTail	10MM	10MM	STD	SR	Collar Cutter	N/A	256BT	2583
99-7920	BobTail	-08	1/4"	SHORT	SR	—	BV4500-118	244BT	2480

*Suggested tool/nose assembly option. Other tooling options may exist. Visit the Tooling Resource Center at AFSHuck.net/Tooling or call HFS at 800-278-4825 or email at sales.kingston@howmet.com for more information





Huck® BobTail® Tooling/Nose Assembly Selection

NOSE ASSEMBLY	FASTENER TYPE	FASTENER DIAMETER	FASTENER DIAMETER	LENGTH	RELEASE (JAWS)	COMMENTS	BATTERY TOOL	PNEUDRAULIC TOOL	HYDRAULIC TOOL
99-7923*	BobTail	-10	5/16"	STD	SR	—	N/A	256BT*	2583
99-7923CC	BobTail	-10	5/16"	STD	SR	Collar Cutter	N/A	256BT	2583
99-7924*	BobTail	-12	3/8"	STD	SR	—	N/A	256BT*	2583
99-7924-2	BobTail	-12	3/8"	LONG	SR	2" Extension	N/A	256BT	2583
99-7924-4	BobTail	-12	3/8"	XLONG	SR	4" Extension	N/A	256BT	2583
99-7924CC	BobTail	-12	3/8"	STD	SR	Collar Cutter	N/A	256BT	2583
99-7924CH	BobTail	-12	3/8"	STD	SR	Chisel Nose	N/A	256BT	2583
99-7925	BobTail	-12	3/8"	LONG	SR	—	N/A	N/A	SFBTT8
99-7925CC	BobTail	-12	3/8"	LONG	SR	Collar Cutter	N/A	N/A	SFBTT8
99-7926	BobTail	-12	3/8"	STD	SR	—	N/A	256BT	2583
99-7927	BobTail	-12	3/8"	STUB	SR	—	N/A	N/A	SFBTT8
99-7928*	BobTail	-12	3/8"	STD	SR	—	N/A	N/A	SFBTT8*
99-7928-1	BobTail	-12	3/8"	LONG	SR	1" Extension	N/A	N/A	SFBTT8
99-7928CC	BobTail	-12	3/8"	STD	SR	Collar Cutter	N/A	N/A	SFBTT8
99-7929*	BobTail	-10	5/16"	STD	SR	—	N/A	N/A	SFBTT8*
99-7929CC	BobTail	-10	5/16"	STD	SR	—	N/A	N/A	SFBTT8
99-7930*	BobTail	-08	1/4"	STD	SR	—	N/A	N/A	SFBTT8*
99-7930CC	BobTail	-08	1/4"	STD	SR	—	N/A	N/A	SFBTT8
99-7932*	BobTail	-08	1/4"	STD	SR	—	BV4500-118	244BT*	2480*
99-7932-1CH	BobTail	-08	1/4"	LONG	SR	1" Extension, Chisel	BV4500-118	244BT	2480
99-7932-4	BobTail	-08	1/4"	XLONG	SR	4" Extension	BV4500-118	244BT	2480
99-7932-4CH	BobTail	-08	1/4"	XLONG	SR	4" Extension, Chisel	BV4500-118	244BT	2480
99-7932CC	BobTail	-08	1/4"	STD	SR	—	BV4500-118	244BT	2480
99-7932CC-4	BobTail	-08	1/4"	XLONG	SR	Cutter Nose, 4" Extension	BV4500-118	244BT	2480
99-7932CH	BobTail	-08	1/4"	STD	SR	—	BV4500-118	244BT	2480
99-7932L	BobTail	-08	1/4"	STD	SR	A1100 is for 6061 AL only	N/A	A1100	2480L
99-7932LCC	BobTail	-08	1/4"	STD	SR	Cutter Nose, A1100 is for 6061 AL only	N/A	A1100	2480L
99-7933	BobTail	-10	5/16"	STD	SR	Aluminum Only	BV4500-118	244BT	2480
99-8001	BobTail	27MM	27MM	STD	SR	—	N/A	N/A	SF60
99BT-M12-CLAT	BobTail	12MM	12MM	LONG	SR	Cutter Nose, 3" Extension	N/A	N/A	SF20
99BT-M12-CRAJ	BobTail	12MM	12MM	STD	SR	Cutter Nose for Stripped Fasteners	N/A	N/A	2624
99BT-M24-IRAV-X	BobTail	24MM	24MM	STD	SR	Coated Anvil	N/A	N/A	SF46-250-02
99BT-M24-IRAV-XA	BobTail	24MM	24MM	STD	SR	Low Swage Anvil w/ coating	N/A	N/A	SF46-250-02
99BT-M16-IRAO-X	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	Coated Anvil	N/A	N/A	BTT35-DT
99BT-M16-IRAO-XA	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	Low Swage Anvil w/ coating	N/A	N/A	BTT35-DT

*Suggested tool/nose assembly option. Other tooling options may exist. Visit the Tooling Resource Center at AFSHuck.net/Tooling or call HFS at 800-278-4825 or email at sales.kingston@howmet.com for more information



Huck® BobTail® Tooling/Nose Assembly Selection

NOSE ASSEMBLY	FASTENER TYPE	FASTENER DIAMETER	FASTENER DIAMETER	LENGTH	RELEASE (JAWS)	COMMENTS	BATTERY TOOL	PNEUDRAULIC TOOL	HYDRAULIC TOOL
99BT-M14-IRAT-X	BobTail	14MM	14MM	STD	SR	Coated Anvil	N/A	N/A	SF20
99BT-M14-IRAT-XA	BobTail	14MM	14MM	STD	SR	Low Swage Anvil w/ coating	N/A	N/A	SF20
99BT-M16-IRAT-X	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	Coated Anvil	N/A	N/A	SF20
99BT-M16-IRAT-XA	BobTail	-20, 16MM	5/8" & 16MM	STD	SR	Low Swage Anvil w/ coating	N/A	N/A	SF20
99BT-M12-IRAT-X	BobTail	12MM	12MM	STD	SR	Coated Anvil	N/A	N/A	SF20
99BT-M12-IRAT-XA	BobTail	12MM	12MM	STD	SR	Low Swage Anvil w/ coating	N/A	N/A	SF20
99BT-32-IRAQ-X	BobTail	-32	1"	STD	SR	Coated Anvil	N/A	N/A	BTT57-DT
99BT-32-IRAQ-XA	BobTail	-32	1"	STD	SR	Low Swage Anvil w/ coating	N/A	N/A	BTT57-DT
99BT-32-IRAV-X	BobTail	-32	1"	STD	SR	Coated Anvil	N/A	N/A	SF46
99BT-32-IRAV-XA	BobTail	-32	1"	STD	SR	Low Swage Anvil w/ coating	N/A	N/A	SF46
99BT-M14-IXAS	BobTail	14MM	14MM	XLONG	SR	5" Extension	N/A	N/A	SFBTT15
99BT-M14-CXAS	BobTail	14MM	14MM	XLONG	SR	5" Extension, Collar Cutter	N/A	N/A	SFBTT15
99BT-M27-IRBH	BobTail	27MM	27MM	STD	SR	—	N/A	N/A	BT60
99BT-M27-CRBH	BobTail	27MM	27MM	STD	SR	Collar Cutter	N/A	N/A	BT60
99BT-M27-IRAW	BobTail	27MM	27MM	STD	SR	—	N/A	N/A	SF60
99BT-M27-CRAW	BobTail	27MM	27MM	STD	SR	Collar Cutter	N/A	N/A	SF60
99BT-M36-IRBA	BobTail	36MM	36MM	STD	SR	—	N/A	N/A	SW120
99BT-M36-CRBA	BobTail	36MM	36MM	STD	SR	Collar Cutter	N/A	N/A	SW120
99BT-M12-IRAN-X	BobTail	12MM	12MM	STD	SR	Coated Anvil	N/A	N/A	BTT25-DT
99BT-M12-IRAN-XA	BobTail	12MM	12MM	STD	SR	Low Swage Anvil w/ coating	N/A	N/A	BTT25-DT
99BT-12-IRAR-X	BobTail	-12	3/8"	STD	SR	Coated Anvil	N/A	N/A	SFBTT8
99BT-12-IRAR-XA	BobTail	-12	3/8"	STD	SR	Low Swage Anvil w/ coating	N/A	N/A	SFBTT8
99BT-M14-IRAN-X	BobTail	14MM	14MM	STD	SR	Coated Anvil	N/A	N/A	BTT25-DT
99BT-M14-IRAN-XA	BobTail	14MM	14MM	STD	SR	Low Swage Anvil w/ coating	N/A	N/A	BTT25-DT
99BT-M12-IXAS	BobTail	12MM	12MM	XLONG	SR	5" Extension	N/A	N/A	SFBTT15
99BT-08-CRBO-SN	BobTail	-08	1/4"	STD	SR	Collar Cutter, Aluminum Only	BV2200, BV4500	244BT	2480

*Suggested tool/nose assembly option. Other tooling options may exist. Visit the Tooling Resource Center at AFSHuck.net/Tooling or call HFS at 800-278-4825 or email at sales.kingston@howmet.com for more information

hfsindustrial.com

Waco Operations

8001 Imperial Drive
Waco, TX 76714-8117
Tel: +1 800-388-4825
Fax: +1 800-798-4825
huck.waco@howmet.com

Kingston Operations

1 Corporate Drive
Kingston, NY 12401
Tel: +1 800-278-4825
Fax: +1 845-334-7333
sales.kingston@howmet.com

Disclaimer: The information contained in this publication is only for general guidance, and is not intended to create any warranty, express, implied, or statutory; all warranties are contained only in HFS's written quotations, acknowledgments, and/or purchase orders. It is recommended that the user secure specific, up-to-date data and information regarding each application and/or use of such products.

Huck and BobTail are trademarks of Howmet Aerospace Inc. and/or its subsidiaries.
© 2020 Howmet Aerospace Inc. All rights reserved. 0721

